


## **Application Procedures**



UseEmerel Multi-Surface Creme Cleanserto remove stubborn spots, build-ups, scuffs, grease, rubber marks and soapscum without scratching the surface.



Shake bottle well and squeeze product directly onto surface or on to wet cloth, sponge, or brush. Loosen soil with rubbing action, rinse. For a bright shine, polish with soft dry cloth. Can be used on porcelain, ceramic, stainless steel and other washable surfaces. Do not use on natural wood.

## Questions: 1-800-558-2332

Always wear personal protective equipment.

© 2018 Diversey, Inc. All Rights Reserved. \*The hummingbird and wing shape logo is a trademark of Diversey, Inc.