



# Suma<sup>®</sup> Optifill<sup>™/MC</sup>

## Dilution Control System for 3 Compartment Sinks



### Supplies Needed



### Detergent and Sanitizer Procedures



1  
Inspect and clean sink of biofilm using green scrub pad. Place stopper in drain.



2  
WASH with Suma Supreme in 110°F. Verify temperature with stem thermometer.



3  
RINSE off detergent with clean, hot water.



4  
SANITIZE with Suma Final Step at 75°F (room temperature) for at least 60 seconds.


NOTE: If there's only a 2 bay sink, use a dishpan as the first or WASH Sink

### Sanitizer Test


Testing must be done in a sanitizer solution that is clean, fresh and at room temperature. Prepare fresh solution at least daily or more often if use solution becomes visibly soiled.



1  
Dispense Suma Final Step Sanitizer at room temperature for 60 seconds.



2  
Allow foam to settle and cool to 75°F. Dip test strip for 10 seconds. Do not shake or swirl.



3  
Compare to QT-40 test strip guide. Tape should read 200-400 ppm.

### IMPORTANT:

- Date mark detergent and sanitizer bottles with date of installation
- Use same bottle until empty before priming new bottle
- There should be a 4–8 in (10–20 cm) clearance between bottom of faucet and top of unit
- There should be a flow rate of 4–8 gpm for optimum performance
- First time usage: Prime unit (30-45 seconds)

Questions: 1-800-558-2332